

Tips and Facts to Optimize the Use of Your Skeeter Defeater™ Automatic Dispenser

1. Observe how the Dispenser sprays, and adjust its placement for the best coverage in your yard specifically.
2. Be aware of wind conditions. Mosquitoes generally cannot be in the open when winds are higher than 5 mph. For best coverage, position the Nozzle on the Dispenser to spray downwind.
3. The Skeeter Defeater Automatic Dispenser is portable and easy to maintain – it's a great item to take camping and to use on patios and decks.
4. When used as directed, the Skeeter Defeater Automatic Dispenser operates for less than 50 cents a day.
5. Weather conditions that cause unusually dark skies (such as storms) can sometimes trick the DUSK/DAWN® Sensor. The sensor measures the light for 10 minutes at a time to help minimize this issue, but it is still possible for dark skies to initiate the sensor and for the Dispenser to release the spray at a time other than dusk or dawn. It is recommended to turn the unit off when such situations arise.
6. The expected battery life for the Remote Control is two years. When you need to replace your Remote Control, you can purchase a new one at SkeeterDefeater.com.
7. Dispenser batteries last for approximately two months when used regularly. It is suggested to change batteries every other time you replace the CRU.
8. The Skeeter Defeater Automatic Dispenser works best as part of an integrated pest management program. Don't entice mosquitoes to come to your yard – drain standing water on a regular basis.
9. Place the unit in direct sunlight for optimal usage. If you want to treat shaded areas, remember to place the Dispenser in open sunlight and point toward the shaded area; do not place the Dispenser in the shaded area.
10. Always point the nozzle away from you when replacing the CRU, and be sure the Dispenser is turned off.